
Regular Maintenance

Cleaning

Clean the machine regularly to ensure optimum printing quality.



For safety, always unplug the power cord before cleaning the machine.


Cleaning Glass Platen

Wipe the glass platen with a soft cloth dampened with alcohol or mild detergent.



✓ IMPORTANT

Do not use thinner or other organic solvents.




Cleaning inside of the Document Processor

Wipe the inside of the document processor with a soft cloth dampened with alcohol or mild detergent.





⊘ IMPORTANT

Do not use thinner or other organic solvents.



Dual scanning area





Cleaning Slit Grass

When using the document processor, clean the slit glass surface and the reading guide with the dry cloth.



⊘ IMPORTANT

Do not use water, soap or solvents for cleaning.



Dirt on the slit glass or the reading guide may cause black streaks to appear in the output.

