

Remove any jammed paper in Right Cover 1




The fixing unit is extremely hot. Take sufficient care when working in this area, as there is a danger of getting burned.


4 If the optional side feeder is installed, detach the side feeder.




Open Right Cover 1.




Close the duplex unit (A5).




Remove any jammed paper.




Open the paper feed unit cover (A1).






(A1) should not be touched until one minutes passes after open the right cover.


6 Remove any jammed paper.




7 Open the fuser cover (A2).




Remove any jammed paper.




Open the cover (A3).




10 Remove any jammed paper.




1 Lift the cover (A4).




12 Remove any jammed paper.




13 Lift the duplex unit (A5).




14 Remove any jammed paper.



15 Remove the paper from the paper ejector.



16 Return the cover to the original position.



17 If the optional side feeder is installed, return the side feeder to the original position.

