


**Ecosys MA3500cifx  
MA4000cifx**

**Waste Toner Replacement**




When the waste toner box is full, the following message will be displayed.  
"Waste Toner Box is full."


## Open the Waste Toner Cover




**Remove the Waste Toner Box.**




**Put used Waste Toner Box into the plastic waste bag.**



**Remove the new Waste Toner Box.**



## Install the Waste Toner Box.



## Close the Waste Toner Cover



**KYOCERA Document Solutions UK**

**Eldon Court, 75-77 London Road,**

**Reading, RG1 5BS**

**Web: [www.kyoceradocumentsolutions.co.uk](http://www.kyoceradocumentsolutions.co.uk)**